

• Keep the baby's room warmer

• Keep the living room comfortable for all

• Keep the master bedroom cooler for sleeping

75°

68°

72°

Ductwork

Sheet metal or flexible
air supply ducts

Dampers are installed inside the
ductwork leading to each zone

Zone Control Panel

Heating/Cooling Equipment

Optimal efficiency furnace, air conditioner
or heat pump, the source of conditioned air

Electronic Air Cleaner

Optional electronic air cleaner removes
dust, pollen, smoke, bacteria, and other
indoor air pollutants

Motorized Dampers

Low voltage motors open (or close)
dampers inside the ductwork directing
conditioned air to the zones that call for it

Humidifier

Optional humidifier adds moisture
to dry air to reduce static and
make breathing more comfortable

Fresh Air Intake

Optional fresh air intake mixes
fresh air with recirculated air
whenever the heating/cooling
equipment is operating